



**NOTES:**

1. SAWCUT AND REMOVE EXISTING AC PAVEMENT & BASE TO FULL DEPTH OR 12" MIN, WHICH EVER IS GREATER.
2. BACKFILL WITH 2 SACK SAND/CEMENT SLURRY.
3. APPLY TACK OIL TO ALL SURFACES PRIOR TO PLACING NEW AC.
4. REMOVE EXISTING SIDEWALK AND CURB AND GUTTER TO NEAREST SCORE JOINT.



CITY OF CAMPBELL  
PUBLIC WORKS DEPARTMENT

APPROVED BY:

*AD*  
AMY OLAY, P.E.  
CITY ENGINEER

DATE:

3/14/22

AC PAVEMENT REMOVAL &  
RESTORATION AT PCC  
IMPROVEMENTS

J:/DETAILS/CAD/C1

DETAIL  
NO.

C-1

NTS